


X CHAIR

CATAS

UNI EN 1335

Box gross weight 20,8 kg – Box box 0,25 m³

Executive chair – mod. 0419S

Structure:

Polished die casting aluminium structure.
 Seat with plastic inner frame, padded with fire retardant polyurethane injected foam, 60 kg/m³ density. Seat slide (70 mm stroke) and positive tilt adjustment.
 High back in black mesh.
 Height and orientation adjustable headrest, black faux leather covered.
 Height and depth adjustable lumbar support.

Plastics:

N2 – Black plastics

Armrests:

BR141 – 3D adjustable black nylon armrests (height/depth/rotation), aluminium structure and PU armrests



Mechanism:

MS11S – synchronized mechanism with 3 tilt limitation adjustment, anti-shock, adjustable tilt intensity by tension control



N – Black



Base:

BG052 – 5 star polished aluminium base Ø 690 mm.



L – Polished

Castors:



R29 – Set of black PP self-breaking castors Ø 65 mm and Ø 11 mm pivot.



R27 – Set of black PP self-breaking hard floor castors Ø 65 mm and Ø 11 mm pivot.



R28 – Set of hollowed black PP self-breaking hard floor castors Ø 65 mm and Ø 11 mm pivot




R21 – Set of chromed PP hard floor castors Ø 60 mm and Ø 11 mm pivot.



P03 – Set of high chromed metal gliders.



P04 – Set of high black nylon gliders.



Box gross weight 20,2 kg – Box box 0,25 m³

Executive chair – mod. 0417S

Structure:

Polished die casting aluminium structure.
Seat with plastic inner frame, padded with fire retardant polyurethane injected foam, 60 kg/m³ density. Seat slide and positive tilt adjustment.
High back in black mesh.
Height and depth adjustable lumbar support.

Plastics:

N2 – Black plastics

Armrests:

BR141 – 3D adjustable black nylon armrests (height/depth/rotation), aluminium structure and PU armrests



Mechanism:

MS11S – synchronized mechanism with 3 tilt limitation adjustment, anti-shock, adjustable tilt intensity by tension control



N – Black

Base:

BG052 – 5 star polished aluminium base Ø 690 mm.



L – Polished

X CHAIR

Castors:



R26 – Set of black PP self-breaking castors Ø 65 mm and Ø 11 mm pivot.



R27 – Set of black PP self-breaking hard floor castors Ø 65 mm and Ø 11 mm pivot.



R28 – Set of hollowed black PP self-breaking hard floor castors Ø 65 mm and Ø 11 mm pivot



R21 – Set of chromed PP hard floor castors Ø 60 mm and Ø 11 mm pivot.



P03 – Set of high chromed metal gliders.



P04 – Set of high black nylon gliders.


X CHAIR user guide

Chair height adjustment.


Pull the lever on the right side of the seat to increase height. Press the lever upwards when seated to decrease the chair height.

**Seat slider adjustment.**

When standing, pull the levers located under the seat on the right-hand side to adjust the seat depth.

**Inclination seat adjustment.**

From a straight position, pull the lever on the left side of the seat to adjust the seat inclination in 3 positions.

**Tilt adjustment.**


Tilt the chair to the desired position and pull the lever upwards. The mechanism will tilt up to the desired inclination.

**Tension adjustment.**


Pull out the tension control and turn clockwise to increase the tilting force and counterclockwise to decrease the tilting resistance.

**Lumbar support height adjustment.**

Raise or lower the lumbar support manually to the desired height.

**Lumbar support depth adjustment.**

Turn the lever to increase or decrease the backrest depth to the desired position.

**Headrest height adjustment.**

Raise or lower the headrest manually to adjust the desired height.

**Headrest tilt adjustment.**

Manually push or pull the headrest to adjust the tilt.

**Armrest height adjustment.**

Press the side button to adjust the height.

**Armrest depth adjustment.**

Manually move the pad to the desired position.

**Pad rotation adjustment.**

Manually rotate the pad to the desired position.

